

# DRY-SPOTTER COMPLETE SET



Stains	Dry 1	Dry 2	Dry 3	Dry 4	Dry 5*	Notes
Adhesives	1 ●				2 ●	See full text
All-purpose adhesive	1 ●				2 ●	See full text
Ball point pen	2 ●			1 ●	3 ●	In subsequent order
Bier		1 ●	2 ●			To dump with water jet
Blood		●				To dump with water jet
Button marks				1 ●	2 ●	See full text
Cacao		1 ●	2 ●			
Chewing-gum	●					Spray of chewing-gum
Chocolate		1 ●	2 ●			
Clear finish	●					
Coca Cola			●			
Coffee		1 ●	2 ●			
Colours	1 ●			2 ●		
Copying-pencil	2 ●			1 ●	3 ●	In subsequent order
Cosmetics	●					
Cream		●				
Dispersed dyes	2 ●	1 ●			3 ●	See full text
Egg – Albumen - Ice-cream		1 ●				
Enamel paint	1 ●				2 ●	See full text
Felt pen				1 ●	2 ●	In subsequent order
Fruits			●			
Grass			●			
Grease	●					
Ink				1 ●	2 ●	See full text
Jam	3 ●	1 ●	2 ●			Different products
Lipstick	1 ●			2 ●		
Make-up	2 ●			1 ●		In subsequent order
Markers				1 ●	2 ●	In subsequent order
Milk	2 ●	1 ●				Let it act longer
Nail-polish	1 ●		2 ●	1 ●	2 ●	See full text
Of leather garments	1 ●				2 ●	See full text
Oil, oil-colours	1 ●				2 ●	See full text
Ointment	●					
Orange juice			●			To dump with water jet
Pitch	●					
Red wine			●			To dump with water jet
Resin	●					
Sauces	2 ●	1 ●				
Shoe-polish	2 ●			1 ●	3 ●	In subsequent order
Soot	●					Cover with DRY SOLO P
Spirits	2 ●		1 ●			To dump with water jet
Sweat		●				To dump with water jet
Tanning agents			●			
Tar	1 ●				2 ●	Use a spatula
Tea			●			
Tobacco			●			
Urine		●				To dump with water jet
Vomit		1 ●	2 ●			To dump with water jet
Wax	●					

**Do not use with acetates, triacetates and natural silk**

G.B.M. Electrochimica S.R.L.

Sede Legale – Via Fiumicino San Mauro 120/130 – 47039 Savignano sul Rubicone (FC)  
 Tel. 0541 930058 r.a. – Fax Comm. 0541 810218 - Fax Amm.ne 0541 815280 - [www.gbmprodottichimici.it](http://www.gbmprodottichimici.it) - [gbm@gbmprodottichimici.it](mailto:gbm@gbmprodottichimici.it)  
 Capitale Sociale € 20.000,00 i.v. - Cod. Fisc. e P.Iva 00958710402 – R.E.A. 192182

# Full text for DRY SPOTTER SET



## General information:

- The special spotters of the DRY SPOTTERS series can be used also for wet-spotting and for post-spotting.
- A hem test is recommended prior to use for silk, viscose, linen and brilliant wool.
- During the pre-spotting we recommend to treat sensitive garments according to the methods for wet-spotting, in order to maintain fibres and colours.

## Special hints :

- We recommend to use special spotters with parsimony!
- If different spotters are indicated in the spotting-table, follow the indicated sequence, but pass from the first product to the second only if the first does not give the hoped effects. Rinse before using the other products.
- If different products are indicated in subsequent order, their efficacy increases also (but in this way textiles can be attacked). **For this reason the given order should always be followed.**
- For stains which swell in water it is possible to increase considerably the effect of the special spotters by spraying water on the stains.
- If water is used, respect the dosage of cleaning-reinforcer.

## Problems with oil and paint stains:

- These stains can give problems, above all in case of paints without solvent, which are insoluble at solid state. The only solution is to freeze the stain with our spray ice and to remove it by brushing.